




**INSTITUTE OF AUTOMATION AND  
COMPUTER SCIENCE**



# El Bestos Muchachos Teamos: Automated Medical Laboratory

Čermák, Jozefovič, Jukić





1. Definition of the Problem, Related Work, etc.
2. Development Tools, Methods, etc.
3. Design and Implementation of a Functional Solution
4. Experiments and Results
5. Conclusion and Future Work




# Definition of the Problem

## Our project is about sorting and dealing with test tubes

- Blood and urine
- Different operation, different goals
- → Automated Medical Laboratory





# Development Tools and Methods

## Robot Studio

- RobotWare 6.15.01
- 2x Robot IRB 120, 1x Robot IRB 1200
- 3x ABB Smart Gripper




Version: 6.15.01 (added) ▾  
Published: 06.02.2023  
Size: 257MB






## Random Generator

- Random test tubes are inserted onto the conveyor



## Random Generator



 Rapid script




```
PROC place_tube()  
  FOR i FROM 1 TO 5 DO  
    x := Rand(\SeedEachNTime:=10)/RAND_MAX;  
    IF x > 0.66 THEN  
      place_blood i;  
    ELSEIF x < 0.66 AND x > 0.33 THEN  
      place_urine i;  
    ENDIF  
  END
```

## Random Generator




### ○ Result





```
PROC place_tube()  
  FOR i FROM 1 TO 5 DO  
    x := Rand(\SeedEachNTime:=10)/RAND_MAX;  
    IF x > 0.66 THEN  
      place_blood i;  
    ELSEIF x < 0.66 AND x > 0.33 THEN  
      place_urine i;  
    ENDIF  
  END
```



## Camera Scanning Simulation




## Camera Scanning Simulation



## Centrifuge blood separation

- Red Blood Cells
- White Blood Cells
- Blood Plasma





CASE 20:

!EXPECTED ROTATION OF CENTRIFUGE

```
SetDO DO_ROTATE_CENT,1;  
WaitTime 4;  
SetDO DO_ROTATE_CENT,0;  
PulseDO DO_CENTRIFUGE_HOME;  
PulseDO DO_HIDE_BLOOD;  
cent_sequence := 30;
```


Rotator
Properties
Object (Centrifuge_holder)
CenterPoint ([0.00 0.00 0.00] mm)
Axis ([0.00 0.00 1000.00] ...)
Speed (180.00 deg/s)
Reference (Object)
ReferenceObject (Frame_2)
I/O Signals
Execute (0)

Hide_10
Properties
Object (Content_Blood_101)
I/O Signals
Execute (0) -----> Executed (0)






# Design and Implementation of Functional Solution

- Blue ... Conveyors
- Red ... Robots
- Green ... Centrifuge, Microscop and starting Base-point










## Camera





## Microscop



## Centrifuge










# Experiments and Results

## Does It Work ?

- ✓ Random Generator
- ✓ All test tubes reach their final positions
- ✓ Smooth and correct Robot arm movements
- ✓ Centrifuge spins and Blood changes Colour



# Conclusion and Future Work

## Future Work

- Join the Competition
- Use ROS with real Camera
- Put it into a Virtual Reality
- Make it real
- *... And Patrik will add like 30 or 40 commands for better feeling*






ROS






## What have we learned

- New skills in Robot Studio
- Teamwork
- Solving complex task



## Video



Downloaded from <https://www.cambridge.org/core>. University of Cambridge, on 01 Jun 2018 at 12:00:00, subject to the Cambridge Core terms of use, available at <https://www.cambridge.org/core/terms>. <https://doi.org/10.1017/9781315325470.008>



# Questions?





**INSTITUTE OF AUTOMATION AND  
COMPUTER SCIENCE**